

# VISHNU INSTITUTE OF TECHNOLOGY


(Approved by AICTE, New Delhi & Affiliated to JNTUK, Kakinada)

Vishnupur, BHIMAVARAM - 534 202

## INDEX

S.No.	Date	Experiment	Page	Marks
1.	05-10-2021	REFLEX KLYSTRON	1-3	(9) ✓ 12/11/21
2.	12-10-2021	ATTENUATION MEASUREMENT	4-6	(9) ✓ 21/11/21
3.	26-10-2021	GUNN DIODE V-I CHARACTERISTICS	7-8	(10) ✓ 21/11/21
4.	2-11-2021	DIRECTIONAL COUPLER	9-11	(10) ✓ 16/11/21
5.	16-11-2021	CHARACTERISTICS OF CIRCULATOR	12-14	(10) ✓ 3/12/21
6.	3-12-2021	SCATTERING PARAMETERS OF MAGIC TEE	15-17	(10) ✓ 17/12/21
7.	17-12-2021	CHARACTERISTICS OF LED	18-20	(10) ✓ 28/12/21
8.	28-12-2021	DATA RATE FOR DIGITAL LINK	21-22	(10) ✓ 4/1/22
9.	4-01-2022	NUMERICAL APERTURE OF OPTICAL FIBRE	23-24	(10) ✓ 11/1/22
10.	11-01-2022	STUDY OF LOSSES IN OPTICAL FIBRE	25-27	(10) ✓ 13/1/22
Total Avg. Marks (Max. Marks 15)				8.167

Block diagram:-



REFLEX KLYSTRON

Aim:- To study the characteristics of the Reflex Klystron.


Apparatus:-

S.NO	Name	Quantity
1.	Klystron Power supply	1
2.	Klystron with mount	1
3.	Isolator	1
4.	Variable attenuator	1
5.	Frequency meter	1
6.	Slotted line	1
7.	Tunable probe and CRO	1
8.	Detector mount  Matched load	1
9.	VSWR meter	1

Theory:-

Reflex Klystron works on the principle of velocity and current modulation. The electron beam is injected from the cathode. The electron beam passes through the accelerating anode. The electron moves in the tube with uniform velocity until it reaches the cavity.

### MODEL GRAPH :-



### Observations:-

S.no	Repeller voltage (Volts)	power		frequency (GHz)	Mode number
		dB	$MW = 10^{(P(dB)/10)}$		
1.	-246	-47	0.0158	9.87	1
2.	-230	-52	0.0063	9.8555	1
3.	-210	-48	0.0158	9.75	1
4.	-196	-39	0.12	9.825	2
5.	-180	-41	0.07	9.8	2
6.	-170	-39	0.12	9.75	2

The velocity of electrons is modulated in the cavity gap and these electrons try to reach the anode. The anode is connected with the negative polarity of a voltage source. Hence, because of the same polarity, it opposes the force of electrons. The kinetic energy of electrons decreases in the anode space and at some point, it will be zero. After that, the electron pulls back to the cavity. And in return journey electrons bunched at the one point. There will be current modulation due to the bunch formation. The energy of electrons are converted in the form of RF and RF Q.P is taken from the cavity. For maximum efficiency of klystron, the bunching of the electron must take place in the centre of the cavity gap.

$$\text{output power } P_{RFmax} = \frac{0.398 V_0 I_0}{N} \text{ watt}$$

#### Procedure:-

1. Connect the components and equipment as shown in the microwave bench. Set the beam voltage control knob to fully anti clockwise and deflector voltage control knob to fully clockwise in klystron power supply.
2. Adjust the beam voltage to 300V and beam current


as 20mA

3. change to the Reflector voltage, such that observe the square wave in the CRO


4. change the Reflector voltage and note down the power output & frequency for different modes and plot in the graph.

Result:-

The characteristics of Reflex Klystron are studied



Block diagram :-



WITHOUT ATTENUATOR

ATTENUATION MEASUREMENT


Aim:- To study the attenuation factor of fixed and variable attenuators.

Apparatus:-

S.NO	Name	Quantity
1.	Klystron power supply	1
2.	Klystron with mount	1
3.	Isolator	1
4.	Variable attenuator	2
5.	Frequency meter	1
6.	Fixed attenuator	1
7.	Slotted line	1
8.	Tunable probe and C.R.O	1
9.	Detector mount / Matched load	1
10	VSWR meter.	1

Theory:-

Attenuation is the reduction of the amplitude of signal, electric current or other oscillation. Attenuators are transmission line components with atleast two ports used to reduce the input power in a system by a predetermined amount.



Fixed attenuators are those whose attenuation is factor present at some nominal level. It is a fixed value and cannot be changed.

Variable attenuators, on other hand can be controlled by the user to vary the attenuation level of the device.

$$\text{power attenuation } A_p = 10 \log_{10} (P_s/P_d)$$

$$\text{in terms of voltage } A_v = 20 \log_{10} (V_s/V_d)$$

#### Procedure:-

1. Connect the components and equipment as shown in the microwave bench setup 1.
2. Set the beam voltage control knob to fully anticlockwise and reflector voltage control knob to fully clockwise in klystron power supply.
3. Adjust the beam voltage to 300V and beam current as 20mA
4. Change to the reflector voltage such that to observe the square wave in the CRO and note down the power output ( $P_1$ ) in VSWR meter.
5. Connect the components and equipment as shown in the microwave bench setup 2 for fixed attenuator and notedown the power output ( $P_2$ )

### Observations:-

Beam voltage : 199V

Repeller voltage : -222V

Input power ( $P_1$ ) : -51dB

for a fixed attenuator


Output power ( $P_2$ ) = -60dB

$$\begin{aligned} \text{Attenuation} &= P_1 - P_2 \\ &= -51 + 60 \\ &\approx 9 \text{ dB} \end{aligned}$$


6. calculate the attenuation  $A(\text{dB}) = 10 \log(P_1/P_2)$
7. Do the steps 4 and 5 by changing the fixed attenuator to variable attenuator by changing the value of attenuation.

Result:-


The Attenuation factor of a fixed attenuator is verified.



### Block diagram:-



SET UP FOR THE V-I CHARACTERISTICS OF GUNN DIODE



## GUNN DIODE V-I CHARACTERISTICS

Aim:- To study the volt-amp characteristics, frequency vs power characteristics.

Equipment Required:-

1. Gunn Power Supply

2. Gunn Oscillator

3. Gunn Diode Mount

4. PIN Modulator

5. Isolator

6. Frequency Meter

7. Slotted Section

8. Tunable Probe.

9. VSWR Meter

10. Movable Short.


Theory:-

The Gunn oscillator is based on negative differential conductivity effect in bulk semiconductors, which has two conduction bands, separated by an energy gap (greater than thermal energies). If a voltage is applied to this device, the most of applied voltage appears across the active region. The electrons from the conduction band

## OBSERVATIONS:-

S.NO	Gunn Bias Voltage (V)	Gunn current (mA)
1	0	0
2	0.45	0.045
3	1.3	0.123
4	2.01	0.182
5	2.66	0.224
6	3.03	0.244
7	3.5	0.270
8	4.34	0.292
9	5.08	0.295
10	5.51	0.252
11	6.6	0.255

## MODEL GRAPH :-




having negligible electrical resistivity are transferred into the third band because these electrons are scattered by the applied voltage. Because of this increase in  $V_a$  increases the field strength (for field strength where  $V_a > V_{th}$ ), then the no of  $e^-$  reaching the state at which effective mass increases by decreasing their velocity and thus current will decrease. Thus if field strength is increased, drift velocity will decrease, this creates a negative incremental resistance region in V-I relationship.


### Procedure:-

1. connect the components and equipment as shown in the Microwave bench.
2. Set the control knob of Gunn Supply in minimum position
3. set the control knobs of PIN Modulator in Gunn Supply in middle position
4. change the Gunn Voltage in steps until GV and note down the Gunn Current.

Result:- Hence, studied the characteristics of the Gunn diode.



### Block diagram:



SETUP FOR THE MEASUREMENT OF DIRECTIONAL COUPLER

## DIRECTIONAL COUPLER

Aim:- To find the parameters of a Directional Coupler.

Equipment required:-


S.NO	Name	Quantity
1.	Klystron Power Supply	1
2	Klystron with mount	1
3.	Isolator	1
4.	Variable attenuator	1
5.	Frequency meter	1
6.	Slotted line	1
7.	Directional Coupler	1
8.	Tunable probe and CRO	1
9.	Detector mount / Matched load	1
10.	VSWR meter.	1

Theory :-

A Directional coupler is a device that samples a small amount of Microwave power for measurement purposes. The power measurements include incident power, reflected power, VSWR values etc.

In directional coupler all terminations are matched to the ports. When the power travels from port 1 to

## DIRECTIONAL COUPLER



Observations:-

Current = 20mA

Voltage = 270V

Repeller voltage = -140V

Reference power  $P_1 = 41\text{dB}$

$P_2 = 34\text{dB}$

$P_3 = 45\text{dB}$

$P_4 = 51\text{dB}$

Insertion loss =  $41 - P_2$

$$= 41 - 42$$

$$= -1\text{dB}$$

point 2, some portion of it gets coupled to point 4 but not to point 3. Being bidirectional coupler, when power travels from point 2 to point 1, some portion coupled to point 3 but not to point 4. If the power is incident through point 3, a portion is coupled to point 2 but not to point 1. Similar case is observed for point 4. Ideally output point 3 should be zero, practically a small amount of power called back power is observed at point 3.

$$\text{coupling factor } C = 10 \log_{10} \frac{P_i}{P_f} \text{ dB}$$

$$\text{Directivity } D = 10 \log_{10} \frac{P_f}{P_b} \text{ dB}$$

$$\text{Isolation } I = 10 \log_{10} \frac{P_i}{P_b} \text{ dB}$$

$$\text{Isolation} = \text{coupling factor} + \text{Directivity}$$

#### Procedure:-

1. Connect the components and equipment as shown in the microwave bench setup.
2. Set the beam voltage control knob to fully anti clockwise and reflector voltage control knob to fully clockwise in klystron power supply
3. Adjust the beam voltage to 300V and beam current as 20mA
4. Change to the Reflector voltage such that to observe the square wave in the CRO and note down the power output ( $P_1$ ) in VSWR meter.
5. Connect the components and equipments as shown in the

Coupling (dB) =  $P_1 - P_3$

$$= 41 - 45 \\ = -4 \text{ dB}$$

Isolation (dB)

$$= P_1 - P_4$$

$$= 41 - 51 \\ = -10 \text{ dB}$$

Directivity (dB)

$$= P_3 - P_4$$

$$= 45 - 51 \\ = -6 \text{ dB}$$

microwave bench with directional coupler and note down the power output ( $P_2$ ) with terminating point 3 and 4.

6. connect the components and equipment as shown in the microwave bench setup 2 with directional coupler and note down the power output ( $P_3$ ) with terminating point 2 & 4.

7. connect the components and equipment as shown in the microwave bench setup 2 with directional coupler and note down the power output ( $P_4$ ) with terminating point 1 & 3.

8. calculate insertion loss  $I = 10 \log (P_1/P_2)$

9. calculate coupling coefficient  $C = 10 \log (P_1/P_3)$


10. calculate isolation loss  $= 10 \log (P_2/P_3)$

11. calculate Directivity  $D = 10 \log (P_4/P_3)$

Result:- Hence we studied and calculated the parameters of a Directional coupler.

16/11/21  
10

### Block diagram:-



### SET UP FOR CIRCULATOR CHARACTERISTICS:

## CHARACTERISTICS OF CIRCULATOR

Aim:- To find the scattering matrix for a 3 port circulator

### Equipment:-

S.NO	Name	Quantity.
1.	Klystron power supply	1
2.	Klystron with mount	1
3.	Isolator	1
4.	Variable attenuator	1
5.	Frequency meter	1
6.	Slotted line	1
7.	3 port circulator	1
8.	Tunable probe and CRO	1
9.	Detector mount / Matched load	1
10.	VSWR meter	1

### Theory:-

The circulator is a ferrite device including two or more ports. When the input signal enters into any port, then the signal will transmit in a particular direction.

There are different models, these components are mainly used in different applications like radar systems

Observation:

Input port	output power	output power	Scattering coefficient
$P_1 =$	$P_2 =$	$P_3$ terminated	$S_{12} = \frac{P_2}{P_1}$
$P_1 =$	$P_2$ terminated	$P_3 =$	$S_{13} = \frac{P_3}{P_1}$
$P_2 =$	$P_3 =$	$P_1$ terminated	$S_{23} = \frac{P_3}{P_2}$
$P_2 =$	$P_3$ terminated	$P_1 =$	$S_{21} = \frac{P_1}{P_2}$
$P_3 =$	$P_1 =$	$P_2$ terminated	$S_{31} = \frac{P_1}{P_3}$
$P_3 =$	$P_1$ terminated	$P_2 =$	$S_{32} = \frac{P_2}{P_3}$

$$P_{\text{ref}} = 40.8 \text{ dB}$$

$$P_{12} = 30.8 \text{ dB}$$

$$P_3 = 58 \text{ dB}$$

amplifier systems etc. The communication of the magnetic field towards the ferrite material within circulator makes magnetic fields related to the flow of water in the cup. The rotating field is extremely strong and will cause any RF signals inside the frequency band at one point to track the magnetic flow toward the nearby point but not in the reverse direction.

#### Procedure:-

1. Connect the components and equipment as shown in the microwave bench setup 1.
2. Set the beam voltage control knob to fully anti clockwise and reflector voltage control knob to fully clockwise in klystron power supply.
3. Adjust the beam voltage to 300V and beam current as 20mA
4. ~~change to the reflector voltage such that to observe the square wave in the CRO and note down the power output ( $P_1$ ) in VSWR meter.~~
5. Connect the components and equipment as shown in the microwave bench setup 2 with circulator and note down the power output ( $P_2$ ) with terminating port 3.
6. calculate the Scattering matrix coefficient  $S_{12} = P_2/P_1$
7. Now calculate the output power  $P_3$  while terminating port 2 and calculate scattering matrix coefficient


$$S_{13} = P_3 | P_1$$

8. Do the step 5 and 6 by giving input to  $P_2$  and calculate  $S_{23}, S_{21}$


9. Do the step 5 and 6 by giving input to  $P_3$  and calculate  $S_{31}, S_{32}$

Result:-

The insertion loss, isolation and scattering matrix of the devices are found.



### Block diagram:-



SETUP FOR MAGIC TEE

## SCATTERING PARAMETERS OF MAGIC TEE

Aim:- To find the scattering matrix of a Magic Tee

Equipment required:-

SNO	Name	Quantity
1.	Klystron Power Supply	1
2.	Klystron with mount	1
3.	Isolator	1
4.	Variable attenuator	1
5.	Frequency meter	1
6.	Slotted line	1
7.	Magic Tee	1
8.	Tunable probe and CRO	1
9.	Detector mount / Matched load	1
10.	VSWR meter	1

Theory:-

A magic Tee is a combination of E and H plan tee, Arm 3 is the H-arm and arm 4 is the E arm. If the power is fed, into arm 3 (H-arm) the electric field divides equally between arm 1 and 2 with the same phase and no electric field exists in arms. If power is fed in arm 4 (E-arm), it divides equally into arm 1 & 2.

Observation:

Current = 20mA

Repeller voltage = 270V

P<sub>W</sub> = 41dB

P<sub>1</sub> = 42dB

P<sub>2</sub> = 43dB

P<sub>3</sub> = 40dB

P<sub>4</sub> = 47dB

but out of phase with no power to arm 3, further, if the power is fed in arm 1 and 2 simultaneously it is added in arm 3 (H-arm) and it is obtained subtracted in E-arm i.e arm 4. The basic parameters to be measured for magic Tee are discussed.

### Procedure:-


1. connect the components and equipment as shown in the Microwave bench setup 2
2. Set the beam voltage control knob to fully anticlockwise and deflector voltage control knob to fully clockwise in Klystron Power Supply.
3. Adjust the beam voltage to 300V and beam current as 20mA
4. Change to the deflector voltage such that to observe the square wave in the CRO and note down the power output( $P_1$ ) in VSWR meter.
5. ~~connect the components and equipment as shown in the Microwave bench setup 2 with Magic tee and note down the power output( $P_2$ ) with terminating port 3 & Port 4~~
6. calculate the scattering matrix coefficient  $S_{12} = P_2 / P_1$
7. Now calculate the output power  $P_3$  while terminating port 2 and port 4 calculate scattering matrix  $S_{13} = P_3 / P_1$

8. calculate the output power  $P_4$  while terminating port 2 and port 3 & calculate scattering matrix  $S_{14} = P_4/P_1$
9. Do the steps 5,6,7 by giving input to  $P_2$  and calculate scattering coefficients  $S_{21}, S_{23}, S_{24}$
10. Do the steps 5,6 and 7 by giving input to  $P_3$  and calculate scattering matrix coefficients  $S_{31}, S_{32}, S_{34}$
11. Do the steps 5,6 and 7 by giving input to  $P_4$  and calculate scattering coefficients  $S_{41}, S_{42}, S_{43}$ .

Result:- The Scattering matrix of magictee is found.

✓ (M) (10)  
C (11) (11)  
19

Block diagram:-



CHARACTERISTICS OF SFH156V

CHARACTERISTICS OF SFH156V

CHARACTERISTICS OF SFH156V

## CHARACTERISTICS OF LED

Aim:- To find the V-I characteristics of LED

Equipment required :-

S.NO	Name	Quantity.
1.	Fibre Link -A kit	1
2.	20 MHz Dual channel oscilloscope	1
3.	1 meter Fibre Cable	1
4.	Voltmeter	1
5.	Ammeter	1.

Theory:-

In optical fibre communication system, Electrical signal is first converted into optical signal with the help of conversion device such as LED or LASER DIODE here. After this optical signal is transmitted through optical fiber, it is retrieved in its original electrical form with the help of conversion device such as photodetector.

Different technologies employed in chip fabrication lead to significant variation in parameters for the various laser diodes. All the laser diodes distinguish themselves in

Observations:-

FOR SFH156V

current(mA)	Voltage(v)
0	1.5
1	1.63
2	1.641
3	1.657
4	1.673
5	1.682
6	1.69
7	1.7
8	1.715
9	1.725
10	1.73
11	1.739
12	1.74
13	1.753
14	1.763
15	1.769

FOR SFH1250V


current(mA)	voltage(v)
0	1.56
1	1.59
2	1.618
3	1.631
4	1.643
5	1.653
6	1.667
7	1.667
8	1.668
9	1.683
10	1.688
11	1.691
12	1.693
13	1.70
14	1.703
15	1.709

offering high output power coupled into the important peak wavelength of emission, conversion efficiency (usually Specified in terms of power launched in optical fiber Peak wavelength of emission, conversion efficiency (usually specified in terms of power launched in optical fiber) for specified forward current) optical rise and fall times which put the limitation on operating frequency, maximum forward current through laser diode and typical forward voltage across laser diode.

An important feature of laser diodes is their ability to respond to direct, high speed modulation. In pulse drive operation, if the DC bias current,  $I_b$  is less than the threshold current  $I_{th}$ , a time delay will result between the drive current pulse and the optical power output pulse. Therefore, the DC bias current is normally set just above the threshold current to obtain quick response

Photodetectors usually comes in variety of forms photoconductive, photovoltaic, transistor type output and diode type output. Here also characteristics to be taken into account are response time of the detector, which puts the limitation on the operating frequency,

## MODELGRAPH :-



CHARACTERISTIC CURVE OF LED



wavelength, sensitivity and responsivity




Procedure:-

1. Switch on the power supply of analog kit
2. Set the jumper setting for the transmitter
3. Connect the voltmeter and ammeter to the jumpers as shown in the block diagram
4. By changing pot P<sub>3</sub>. Note down voltage current and plot the graph.

Result:-

The characteristics of LED are found.

## Block Diagram :-



SWITCH FAULTS

P.No 21

DATA RATE FOR DIGITAL LINK

Aim:- To setup a fibre optical digital link and find the data rate.

Apparatus required:-

S.NO	Name	Quantity.
1.	Fibre Link - A kit	1
2.	20 MHz Dual channel Oscilloscope	1
3.	1 meter Fiber cable	1
4	Function Generator	1

Theory:-

Fibre optic links can be used for transmission of digital as well as analog signals. Basically a fibre optic link contains three elements a transmitter, an optical fibre and a receiver.

The transmitter module takes the input signal in electronic form and then performs it into optical energy carrying the same information. The optical fibre is the medium which carries this energy to the receiver. At the receiver, light is converted back into electric form with the same pattern as originally fed to the transmitter.

### Observation :-

$$V_{in} = 4.96 \text{ V} \quad f_{eq} = 700 \text{ Hz}$$

S.NO	Frequency (Hz)	OpP (v)	OpP(dB) gain
1.	188	4.96	0dB
2.	3K	6.15	1.867
3.	5K	6.9	2.867
4.	7K	6.6	2.481


Thus LED emits full intensity of light at this time. This variation in the intensity has linear relation with the input electrical signal. Optical signal is then carried over by the optical fiber.

### Procedure:-


1. Switch on the power supply of antilog kit
2. Set the Jumper setting for the transmitter 650nm
3. Connect the optical fibre from transmitter to receiver
4. Give the square wave input to the transmitter and observe the output
5. Change the data rate of the input and observe the output for constant input vi for different data rates.

### Result:-

An optical fibre link is established. The frequency response is observed and graph drawn between gain(db) vs frequency (Hz)



## BLOCK DIAGRAM FOR NUMERICAL APERTURE & SETUP:-



## NUMERICAL APERTURE OF OPTICAL FIBRE

Aim:- To find the numerical aperture of optical fibre

Equipment Required:-

S.NO	Name	Quantity
1.	Fibre Link A kit	1
2.	20MHz Dual channel oscilloscope	1
3.	1 meter fibre cable	1
4.	Steel Ruler	1
5.	Power Supply	1

Theory:-

Numerical aperture refers to the maximum angle at which the light incidents on the fibre end is totally internally reflected and is transmitted properly along the filter. The cone forward by the rotation of this angle along the axis of the fibre is the cone acceptance of the fibre. The light may strike the fibre end within its cone of acceptance else it is refracted out of fibre cone.

Observation:-

Distance between source and centre of circled path $d = \text{cm}$	Vertical diameter MR (cm)	Horizontal diameter PN (cm)
1	1.4	1.3
1.5	1.7	1.6
2	2.0	1.8

$$\text{Mean radius } \sigma_1 = \frac{MR + PN}{4} = \frac{1.4 + 1.3}{4} \Rightarrow \sigma_1 = 0.625 \text{ cm}$$

$$\text{Numerical aperture } N.A = \sin \theta_{\max}$$

$$N.A = \frac{\sigma_1}{\sqrt{\sigma_1^2 + d^2}}$$

$$= \frac{0.625}{\sqrt{(0.625)^2 + 1^2}}$$

$$N.A = 0.529$$

Procedure:-


1. Switch on the power supply of analog kit
2. Set the jumper setting for the transmitter.
3. Keep the point P<sub>3</sub> fully clockwise and P<sub>4</sub> fully anti-clockwise
4. Adjust point P<sub>3</sub> and P<sub>4</sub> such that illuminated circular path of light on the screen.
5. calculate the diameters M<sub>R</sub> and P<sub>N</sub> indicated in the figure and also d.
6. calculate  $\alpha_1 = (M_R + P_N) / 4$
7. calculate the numerical aperture of the fibre by using the formulae.

$$N.A = \sin \alpha = \frac{\alpha_1}{\sqrt{d^2 + \alpha_1^2}}$$

Result:- The numerical aperture of the optical fibre is found.



$$11.11 \times 10^{-2}$$

## BLOCK DIAGRAM FOR LOSS MEASUREMENT:-





## JUMPER SETTING DIAGRAM :-

FOR  $Tx_1(SFH 450V)$



SWITCH FAULTS



## STUDY OF LOSSES IN OPTICAL FIBRE (OVL)

### FIBRE OPTIC LOSSES

Aim:- To find the losses of fibre optic cable

#### Equipment required:-

S.NO	Name	Quantity.
1.	Fibre link-A kit	1
2.	20MHz Dual channel oscilloscope	1
3.	1 meter fibre cable	1
4.	3 meter fibre cable	1

#### Theory:-

Optical fibres are available in different variety of materials. These materials are usually selected by taking into account their absorption characteristics for different wavelengths of light. In case of optic fibre, since the signal is transmitted in the form of light, which is completely different in nature as that of electrons one has to consider the interaction of matter with the

### Observation:-

input voltage ( $V_i$ ) = 2V      frequency 1 KHz

S.NO	Diameter (cm)	output voltage (volts) $V_o$	Frequency (Hz)	loss in dB $= -20 \log_{10}(\frac{V_o}{V_i})$
1.	9cm	1.29V	1 KHz	3.80 dB
2.	15cm	1.41V	1 KHz	3.03dB
3.	1m	1.42V	1 KHz	2.974 dB
4	3m	1.1V	1 KHz	5.1927 dB

### Attenuation:-

$$\alpha = \left[ \frac{10}{L_1 - L_2} \right] \log \left( \frac{V_2}{V_1} \right)$$

$$L_1 = 1m \quad V_1 = 1.42V$$

$$L_2 = 3m \quad V_2 = 1.1V$$

$$= \frac{10}{(1-3)} \log \left( \frac{1.1}{1.42} \right)$$

$$\alpha = 0.55 \text{ dB}$$


radiation to study the losses in fibre. Losses are introduced in fibre due to various reasons. As light propagates from one end of fibre to another end, part of it absorbed in materials exhibiting absorption loss. Also part of this light is reflected back or in some other directions from the impurity particles present in the material contributing to the loss of the signal at the other end of the fibre. In general terms it is known as propagation loss.

Plastic fibres have higher loss of the order of 180 dB/km. Whenever the condition for angle of incidence of the incident light is violated the losses are introduced due to refraction of light. This occurs when fibre is subjected to bending lower the radius.

#### Procedure:-

1. Switch ON the power supply of analog kit
2. Set the ~~jumper~~ settings for the transmitter 650 nm
3. Connect the optical fibre from transmitter to receiver
4. Give the sinusoidal input to the transmitter and observe the output
5. For length  $L_1 = 1\text{ m}$ , find the output  $V_1$ .

### MODEL GRAPH:-



6. For length  $L_2 = 3\text{m}$ , find the output  $v_2$ .

7. Attenuation  $\alpha$  is calculated by using the formulae.

$$\alpha = \left( \frac{10}{L_1 - L_2} \right) * \log \left( \frac{v_2}{v_1} \right)$$

8. Find the bending losses by doing steps 1 to 7 after bending the fibre.

Result:-

The attenuation factor ' $\alpha$ ' is found. The bending loss is found for four different diameters of curvature.

